

JERIC

Hardwood and Laminate Flooring Protector

- ❖ Provides protection against moisture and humidity for urethane and wax finished hardwoods

Wood Flooring Protector

Description	Hardwood and laminate flooring protector will help protect flooring from moisture and humidity. To keep floor protected, we recommend re-applying Hardwood and Laminate Flooring Protector every three months. To keep the floor clean, use Hardwood and Laminate Floor Cleaner.
Application	Spray Hardwood and Laminate Flooring Protector directly onto the wood floor and wipe with clean sponge or terrycloth mop. Make sure the entire floor surface has been coated with protector. Continue wiping floor until dry. Once the floor is dry, normal traffic may resume. Clean floor when needed with Hardwood and Laminate Floor Cleaner.
Note	It is always recommended to test this product on a hidden or less visible area before use.
Coverage	Covers approximately 800 to 1,000 sq. ft. (75-93m ²) per 473ml bottle